



Eglu Go 1m Run Extension Instructions




What you have received:



Step A - Unclip the end of your Eglu Go run



Step B - Attach your extension panels - see next page for clip positions




Step C - Re-attach the end of you Eglu Go run

10/15

Clip positions for your Eglu Go 1m Extension

Note: Double run clips are highlighted with a darker edge



For more information or advice please call Omlet on:

| | | |
|------------|----------------|------------------|
| GB | 0845 4502056 | info@omlet.co.uk |
| DE | +49 9113749075 | hallo@omlet.de |
| USA | 1-866-6538-872 | info@omlet.us |