


Omlet®



eglu®
cube
2m run

Watch the 'How to Build' video now
www.omlet.co.uk/how_to_build





United Kingdom	01295 500900	hello@omlet.co.uk	www.omlet.co.uk
United States	646-434-1104	info@omlet.us	www.omlet.us
Australia	02 8103 4124	info@omlet.com.au	www.omlet.com.au
Ireland	01 513 7973	hello@omlet.co.uk	www.omlet.ie
Deutschland	0451 8118 9058	hallo@omlet.de	www.omlet.de
Austria	0720 115240	hallo@omlet.de	www.omlet.de
France	04 11 92 12 80	info@omlet.fr	www.omlet.fr
Nederland	085 888 3571	vragen@omlet.nl	www.omlet.nl
Belgium FR	02 808 85 07	info@omlet.fr	www.omlet.fr
Belgium NL	09 298 04 69	vragen@omlet.nl	www.omlet.nl
Switzerland DE	022 518 24 59	hallo@omlet.de	www.omlet.de
Switzerland FR	021 588 14 88	info@omlet.fr	www.omlet.fr
Italia	0294 752010	info@omlet.it	www.omlet.it
España	0932 201 199	info@omlet.es	www.omlet.es
Sverige	084468 6558	hej@omlet.se	www.omlet.se
Danmark	89 87 06 83	info@omlet.dk	www.omlet.dk
Norge	08 4468 6558	hei@omlet.no	www.omlet.no
Polska	22 307 01 69	czesc@omlet.com.pl	www.omlet.com.pl



Safety Notice


The run is designed to be used outdoors for years to come. However, we recommend that you check your run regularly for signs of corrosion especially if you live somewhere with extreme weather conditions or close to the sea. Corrosion will occur if the coating has been scratched or scraped for example. If you do see some, remove any loose rust and touch up with a weather resistant paint.

What you have received

064.0146: Mesh Run Box D



Frame Rear Panel 14mm
064.1266
x2




Frame Side Panel 14mm
064.1265
x2




Run Side Panel
064.1067
x2



Run Side Panel 14mm
064.1267
x2



Run Roof Panel
064.1068
x2



Run Front Infill Panel
064.1069
x1




Run Front Half Panel 14mm
064.1270
x2




Run Door Panel
064.1072
x1



Run Door Panel 14mm
064.1272
x1




Skirt Corner Panel
064.1073
x4



Skirt Straight Panel
064.1074
x4



Run Door Pin
810.0011
x2



Skirt Supports
064.1078
x2

810.0138: Bagged Omlet Badge




Omlet Badge
810.0137
x2

810.0024. 082009: Bagged Run Clips



Run Clip
810.0135
x82



Double Run Clip
810.0001
x9

064.0065: Fixings Pack



Rectangular Washer
800.0190
x8



M6x16mm Screw
800.0241
x8

810.0142.012: Bagged Zip Ties



Cable Tie
800.0103
x12

810.0188.032 Bagged Run Clips 11mm



Run Clip
11mm
810.0184
x32

064.0080: Bagged Wheel Arm Track




Wheel Arm
Track Guard
064.1188
x2




Cable Tie
800.0103
x16

Run Exploded Assembly





• Assembling your Eglu Cube •



Tip: Warm your clips in warm water to make them easier to

How to attach Run Clips (810.0135 + 810.0184)



How to attach Double Run Clips (810.0001)








Diagram showing all run clip positions






810.0001



810.0135




You will need...




If you don't have wheels please ignore them



1




2




3





Thread all cable ties through loosely first, then tighten





4



5



6





064.1163
x2




These parts came with the frame - If you don't have them, spares are available online

7

If you don't have wheels please ignore them



064.0068






064.0069

8

x4






Repeat on other side




064.1265




9




10



11



12



13

x2




800.0241

x2



800.0190



14

x4




810.0135

x2




800.0241


x2




800.0190



064.1068






15





If you have any run extensions please refer to those instructions now



16




17




18




19





20







21




22





23



(Run and wheels not shown for clarity)




24





25




26





27









28





29








32







33







064.0014




35



36







37





38



064.0011







39




40





41




42




43




44







45






46






47





48





To unlock the T-handle, push the button and twist the handle at the same time.





or


oder · ou · of · oppure · o · eller · lub




To lock the T-Handle, turn it to its horizontal position and ensure the push button springs up.



If you need to remove the lock, use a flat head screwdriver to lift out the screw caps (810.0443 + 810.0444).





Partition: The partition is used to keep your chickens in the roosting area at night



Deep Clean




Empty Droppings Tray



Make sure the clip engages when putting the tray back.



To attach an Omlet perch to the lower half of the run with the smaller mesh pitch, please see the information below



You will need...




Do not use



- DE Verwende nicht
- FR Ne pas utiliser
- NL Gebruik niet
- IT Non usare
- ES No utilice
- SE Använd inte
- DK Brug ikke
- NO Ikke bruk
- PL Nie używać



053.1022







800.1025





To attach an Omlet Autodoor to the lower half of the run with the smaller mesh pitch, please see the information below. All other steps must be completed as explained in the Autodoor manual.





DOs

Collect and enjoy your eggs everyday. Leaving eggs in the Eglu Cube can cause your chicken to go broody and not lay any eggs for a few weeks.

Make sure your chickens always have access to food and clean water.

Let your chickens out of the Eglu Cube everyday. If you are away, then leave the Eglu Cube door open so that the chickens can get out into the run in the morning. Not letting your chickens out will lead to distressed chickens and could lead to terminal overheating.

Supervise children when they are using the Eglu Cube or interacting with the chickens.

Take extra care when using the lawn mower around the 'skirt' of the run. Without care you will damage the 'skirt' with the lawn mower.

Wash your hands thoroughly after coming into contact with the Eglu Cube or chickens.

Be aware that chickens have sharp beaks and claws and they may peck or scratch at something that resembles food or looks interesting to them. Small shiny things are especially attractive to chickens.

Check that the run door and rear panel are well secured. If they are not secure your chickens are at greater risk of escape and predators.

DON'Ts

Do not sit or climb on the run. This is not only dangerous but can lead to the run being damaged.

Do not let children inside the run or Eglu Cube. This could lead to them getting stuck.

Do not leave the door of the run open while your chickens roost at night. This will compromise your chickens safety by allowing predators to get into the run.

Do not keep the Eglu Cube on uneven ground as this will make the run less secure. It can also cause the run 'skirt' to be a tripping hazard.

Do not use bleach, solvents or strong detergent to clean the Eglu Cube. they could damage the plastic.

Do not keep the Eglu Cube near sources of ignition, such as a bonfire or barbecue, because they could set the Eglu Cube on fire.

Do not use the Eglu Cube to house animals other than chickens. It has not been designed for any other purpose.

Do not keep more than 6 heavy breeds, 8 medium sized breeds or 10 small breeds in the Eglu Cube with the standard run and extension.



Omlet®



Please Reuse,
Compost,
Recycle.

© Copyright Omlet Ltd. 2023
Design Registered, Patent Pending
Eglu is a Registered Trademark of Hebe Studio Ltd.
Omlet is a Registered Trademark of Hebe Studio Ltd.
820.3240 Instruction Manual Box D Run RP 12/04/2023