

EGLU PRO

Run Extension assembly guide



Omlet

What you have received

114.0108 Eglu Pro Box J Run Extension




X2

Extension Pole Side
064.1076




X2

Extension Skirt Support
064.1078




X2

Run Panel Skirt Straight
064.1074



X2

Run Panel Roof Side
114.1204



X3

Run Panel Upper
114.1205




X1

Run Pole Top Left
114.1211



X1

Run Pole Top Right
114.1212



X2

Run Panel Side 14mm
064.1267



X1

Run Roof Brace Tube
810.0505

114.0130 Eglu Pro Run Extension Fasteners Pack

810.0024.006000 Bagged
Mighty Clip A



X6

810.0135

810.0139.038 Bagged
Mighty Clip C



X38

810.0134

810.0189.030 Bagged
Mighty Clip E



X30

810.0185



X1

Run Roof Brace
Double Hook
810.0512

810.0210.002 Bagged
Hook Tube Bungs




X2


810.1067

You will need...

Can be found in 114.0100 Eglu Pro Box A Frame



Assembling your Eglu Pro







The run is designed to be used outdoors for years to come. However, we recommend that you check your run regularly for signs of corrosion especially if you live somewhere with extreme weather conditions or close to the sea. Corrosion will occur if the coating has been scratched or scraped for example. If you do see some, remove any loose rust and touch up with a weather resistant paint.

Tip: Warm your clips in warm water to make them easier to use


How to attach Mighty Clips A,C,G (810.0131, 810.0134, 810.0135)



How to attach Mighty Clips E (810.0185)




If you are attaching your Extension Run directly whilst assembling your Eglu Pro Run:



→ 1

If you are attaching your Extension Run to your fully assembled Eglu Pro Run:



→ 4

1


Box G



X8
810.0134



X2
800.0472



2



Box G


Mesh roof panel not shown for clarity.

Box J





X4

810.0185



3







5


Please keep this part safe until step 16

Box J







7




8

Box J








11



X6
810.0185



12


Box J



X8
810.0134



X6
810.0185



13


Box J



X8
810.0134




X8
810.0185




14

Box H



15



16


Box G

Box J



X2


810.0185



17



X14
810.0134




18

Box J



X8
810.0185

114.1205




19



X8
810.0134





X4
810.0185




20


Box G

Box H





Box G





23

Box J



If you still need to assemble the rear door panels, the arm track guards and two skirt supports and two run door pins please refer to step 20 onward of the Eglu Pro Run manual now.



Box G

Box H



X2

Run Panel Door Rear
114.1209




X2

Arm Track Guards
064.1188



X2

Run Door Pin
810.0011.002



X2

Skirt Support
064.1078



WAHOO, WE'LL DO IT FOR YOU

Here's a little light reading for the bookworms, with our top tips on moving your chickens into their plush new pad.

How to transition your
chicks into their Eglu
chicken coop



THE CROWD PLEASER



Omlet



Please
reuse &
recycle.

© Copyright Omlet Ltd. 2025
Design registered, patent pending
Omlet and Eglu are registered trademarks of Hebe Studios Ltd.
820.0947_Instruction Manual Eglu Pro Run Extension_ 29/05/2025

