
SMART FAN

Assembly Guide



Omlet



Important Information! Please read before use


Thank you for buying an Omlet Smart Fan. It is designed for attachment to your Eglu Pro or to a wooden coop. The Smart Fan ensures a cool and comfortable environment for your chickens by ventilating stagnant hot air that builds up throughout the day, keeping the air fresh inside the coop. Please make sure you read this manual carefully while assembling the product. It is only suitable for use inside the Eglu Pro or a wooden coop. You must follow the assembly and maintenance instructions to ensure the product works as intended. Any other use beyond what is specified shall be considered improper use. Direct commercial or industrial use is also deemed improper. Omlet is not liable for any damage caused from such use. This product requires an external power source. Please note that the Smart Fan may require maintenance throughout its use. Do not carry out maintenance before unplugging the Smart Fan from the power source. If you are uncomfortable with using power tools, please seek professional advice.

Scan a QR code below to download the Omlet app









Interfering with the fan while in motion may cause injury and damage the fan



What you have received

117.0021 Boxed Smart Fan



X1 Smart Fan 117.0012



X1 Inner Logo Plate 114.1135



X1 Outer Logo Plate 114.1136.0002



X1 Cardboard Insert 820.2680

Keep cardboard insert if attaching to a wooden coop





US Power Supply 2.5m 117.1008



or

EU Power Supply 2.5m 117.1010



or

UK Power Supply 2.5m 117.1003



or

AUS Power Supply 2.5m 117.1009

117.0022 Boxed Fan Fixings Pack X2 **X4 X4** X2 **Wood Screw** Wood Screw M6 x 12mm Cable Management 3.5x10mm 5x16mm Bolt Clamp 800.0515 800.0353 117.1002

Screws provided are for wooden coops with a wall thickness above 3/8" (10mm). For thinner walls, follow recommendations for Step 9.

800.0509




You will need...


For attachment to Eglu Pro



For attachment to a wooden coop





Eglu Pro







Wooden Coop




















Untighten and bend tabs to thread cable under channel cover, then retighten. **114.1130** Tray Runner removal optional for easier access.










Smart Fan Assembly to a Wooden Coop Exploded View







Measure appropriate distance from the roof












Sand edges smooth









A supporting sheet of wood is recommended for walls thinner than 3/8"(10mm)







114.1135












Dust Filter Removal:

- 1. Unplug Fan before removing filter casing.
 2. Pull latch to remove filter
 3. Clean with compressed air or a microfibre cloth
 4. Reinsert the filter into the Smart Fan casing







© Copyright Omlet Ltd. 2024
Design registered, patent pending
Omlet is a registered trademark of Hebe Studio Ltd.
820.2701_Instruction Manual Smart Fan_17/05/2024





Points de collecte sur www.quefairedemesdechets.fr Privilégiez la réparation ou le don de votre appareil!

