




What you have received





Run Clips



4 Bolts & Washers
situated in the Front
Face of the eglu




Shade



2 Square
Skirt Panels

**What should I do
with the packaging?**




If your eglu arrived by courier, please remember to retain all the packaging it arrived in. In the case that you wish to return the eglu or any part of the eglu, it must be sent back in the original packaging and have no more than normal wear and tear to receive the full product refund.

Other things you might need



Around 45 minutes to assemble your eglu




A Phillips Screwdriver

Assembling Your Eglu

Step 1 - Find a suitable surface and location in your garden

Make sure you assemble the eglu on a spot that is reasonably even and flat. The diagram shows the eglu dimensions only. Make sure you leave enough space behind the eglu to allow the dropping tray to be removed and enough room in front to open the run door.



Step 2 - Attach Small Run Panels to the Eglu


Take the Lid off the eglu by removing the pin and sliding the locking bar - see page 5 for a complete guide.

Place the Base Unit on the ground and line up the Small Left Run Panel with the Base Unit as shown.

Secure the panel by using the Bolts and Washers. You should bolt it to the top hole on the front face first. Screw it on loosely making sure that the middle edge of the Run Panel is in the centre of the eglu.

Now screw the bottom of the Panel to the eglu, making sure that the Panel sits closely against the plastic along its whole length. Tighten the bolts.

Now repeat this procedure for the other Small Run Panel.




How do I use the Run Clips?




To join two run panels together, you need to use the Clips supplied. Simply spread the arms and place around the two wires to be joined. Squeeze the clip and it will close up and join the wires as shown in the diagram.

If you wish to undo a clip, spread the 'arms' apart. You may find it easier to use a coin to spread the arms.



Step 3 - Clip the Small Run Panels together


Attach the two Small Panels together along their top edges in the positions shown by a ☉



Step 4 - Clip the Large Run Panels on


Attach the panels Large Left Run Panel and Large Right Run Panel using the clips along their edges.

Do not overlap the panels, just line the edges up and clip together.



Step 5 - Clip the Large Run Panels together


Clip the two Large Run Panels together in the positions shown.



Step 6 - Clip the End Panel on


To attach the Run End Panel, line up the centre of the panel with the centre of the run. Put the first clips on each side in the positions shown by the arrows before putting the rest of the clips on.

Repeat this for the other side.




Step 7 - Clip the End Skirt Panel on

To attach the End Skirt Panel, line up the centre of the Panel with the centre of the run then underlap it by one mesh hole - see closeup. Now clip the Panel on.





Step 8 - Clip the Square Skirt Panels on

Attach the square run panels by sliding underneath the eglu and Run panel and clipping in the positions shown.



Step 9 - Attach the Accessories


Shade - This is held on with three hooks on bungee cords as shown. Hook the corners onto the run making sure that it is held reasonably taut to prevent it flapping in the wind.




If you have any problems assembling your eglu call us on **0845 450 20 56** or email **info@omlet.co.uk**

Guide to Using Your Eglu

How to use the Front Door



Firstly, pull the handle at the top of the house up until it stops.



Turn the handle to close the door.





Lock the door by pushing the handle back down until it stops.


Removing the Lid




To take the lid of the eglu off, the first step is to remove the lynch-pin as shown above.



Now simply pull the lock bar out as far as it will go and lift the lid off. This will give you full access to the inside of the eglu.



Closing the Side Hatch



To put the side hatch on, align the bottom edge of the lid.




Push the top corner into place.



Now twist the handle clockwise until you feel it 'click'.




Hayrack and Water Bottle



The hayrack, waterbottle and treat bowl can all be removed through the side hatch. This allows you to fill them up where you store the food without having to take the lid off the eglu and running

Using the Bedding Tray



To empty the bedding tray, firstly take the lid off. You can now lift the tray out using the two handles on either side of the tray.

Moving your eglu

Hold on to the run at the end furthest from the eglu, lift and then pull the eglu to a new patch of grass. The underside of the eglu is smooth and rounded allowing you to slide it around without the need for any dis-assembly.

If you want to move the eglu to a new garden then you will need to take the run apart. Firstly undo the four bolts that hold it to the eglu and then unclip the run. If you lose any clips along the way you can get more by going to www.omlet.co.uk/shop